



Red Line: Measure from the edge of the wood to the yellow line. The yellow line can be anywhere you want the cuff to stop, but cannot extend past the thumb break in the pistol grip.

Green Line: Measure the total circumference around the butt of the stock, along the edge of the wood. The line needs to be in a straight line from top edge to bottom edge. Do not follow the contour if the stock edge if the edge is not straight.

Yellow Line: The yellow line is also a straight line measurement around the stock at the point the cuff will end.

Orange Line: measure from the edge of the wood, as centered as possible, along the bottom to the edge of the sling stud.